

Product Specification

Object	Plug/Adaptor							
Type	Pen Type							
Product	NEOCLEAN-E			NEOCLEAN-EZ				
	E1	E2	E3	EZ1	EZ2	EZ3	EZ1 Plus	EZv
Model#	ATC-NE-E1	ATC-NE-E2	ATC-NE-E3	ATC-NE-EZ1	ATC-NE-EZ2	ATC-NE-EZ3	ATC-NE-EZ1P	ATC-NE-EZv
Compatible Connectors	MU, LC	SC, SC2, FC, FAS, FA	SC, FC, ST, E2000, PC/APC	MU, LC	SC, SC2, FC, FAS, FA	SC, FC, ST, E2000, SMPTE304M*	ODC, LC, MU, Ø1.25mm Ferrule Connector	Ø2.0mm Ferrule Connector for HDTV*
Size (mm)	L:240	L:230	L:230	L:104 (with attachment:113 / extended:167)	L:109 (with cap:121)	L:107 (with cap:113)	L:109 (with cap:121)	L:109 (with cap:121)
Usages	Over 750 times			Over 400 times				
Consumables	Type	Replaceable Cartridge			Disposable Type			
	Product	Cartridge (3 units/set)						
	Model#	ATC-NE-ES1	ATC-NE-ES2	ATC-NE-ES3				

* Compatible with other types of hybrid connector for HDTV.

Object	Plug/Adaptor		
Type	Pen Type		
Product	NEOCLEAN-F	NEOCLEAN-M	NEOCLEAN-M2
	Model#	ATC-NF-12	ATC-NF-25
Compatible Connectors	MU, LC (PC/APC)	SC, FC, ST, E2000 (PC/APC)	MPO, MTP® (Pins yes/no) MPO-16, MTP®-16 (Pins yes/no)
Size (mm)	L:163 (not including attachments) × W:15 × H:22		L:197 (not including attachments) × W:15 × H:51
Usages	Over 1000 times		Over 600 times
Consumables	Disposable Type		Disposable Type

Object	Plug						
Type	Click Type Cassette						
Product	OPTIPOP				CLETOP-S		
	R1	R2	R3	R4	A Type	B Type	
Model#	ATC-RE-01	ATC-RE-02	ATC-RE-03	ATC-RE-04	14110501	14110601	
Compatible Connectors	Single core, Multi-core (no pin)	Single core	MT, MPO (with pin)	MT-RJ (with pin)	Single core (ideal for ø2.5mm)	Single core, Multi-core (no pin)	
Size (mm)	W:124 x D:35 x H:83				W:125 x D:35 x H:85		
Usages	Over 400 times				Over 400 times		
Consumables	Type	Replaceable Cartridge (6 reels/set)				Replaceable Cartridge (6 reels/set)	
	Product	OPTIPOP RS				Blue Tape / White Tape	
	Model#	ATC-RS-01				14110700 / 14110710	

Object	Plug					
Type	Lever Type Cassette				Simple Type	
Product	CLETOP				NEOCLEAN-R2	
	A Type	B Type	MT-RJ Type	MPO Type	ATC-NE-R2	
Model#	14100501	14100601	14100101	14100201	ATC-NE-R2	
Compatible Connectors	Single core (ideal for ø2.5mm)	Single core, Multi-core (no pin)	MT-RJ (with pin)	MT, MPO (with pin)	Single core, Multi-core (no pin)	
Size (mm)	W:130 x D:40 x H:75				W:115 x D:25 x H:55	
Usages	Over 400 times				Over 400 times	
Consumables	Type	Replaceable Cartridge (6 reels/set)				Disposable Type
	Product	Blue Tape / White Tape				
	Model#	14100700 / 14100710				

Object	Adaptors					
Type	Stick Type					
Product	NEOCLEAN-S		CLETOP Stick			
	S125	S250	1.25mm Type	2.5mm Type	2.0mm Type	2.0/2.5mm Double ended
Model#	ATC-ST-01N	ATC-ST-02N	14100401	14100400	14100402	14100403
Compatible Connectors	ø1.25mm	ø2.5mm	ø1.25mm	ø2.5mm	Connectors for High Vision Cameras	
Length (mm)	Max. 152 - Min. 45		101	147	147	151
Packing Specifications	250 sticks/set		200 sticks/set		200 sticks/set	100 sticks/set

Notes:
 * CLETOP, OPTIPOP and NEOCLEAN are trademarks of NTT Advanced Technology Corporation.
 * "MTP" is a registered trademark of US Conec Ltd. Other company names, product names, etc. recorded herein are trademarks or registered trademarks of each respective company.
 * Please understand that the contents recorded herein may be subject to change without notification.
 * Catalog contents from January, 2023 to present.

For more information,
please contact

https://keytech.ntt-at.co.jp/en/optic1/index_s.html



NTT-AT OPTICAL CONNECTOR CLEANER LINEUP
NEOCLEAN™ CLETOP™ OPTIPOP™ SERIES



The pioneer in optical connector cleaners,
brings to you the highest quality cleaning tools.





Supporting reliability in telecommunications service: NTT-AT's Optical Connector Lineup

The cause of many troubles in optical communication equipment is contamination on the end face of optical connectors. NTT Advanced Technology's optical connector cleaners use fiber developed specifically for optical connectors, so even the smallest contaminants not visible to the naked eye are removed. Engineered with both highly portable compact designs and ease of operation in mind, and since no cleaning fluids are necessary there are no special needs for the operating environment either. We have prepared a full lineup of cleaners compatible with every type of optical connector. Please put our technology to work for you.

Why is cleaning optical connectors so important?

Optical connector end face is easily contaminated, and when contaminants adhere to the 10µm diameter optical fiber core, there is a high chance of transmission quality being affected. Since there is also the danger of fiber end face being damaged by high power light, cleaning is necessary before making a connection.




*1: For ferrule end face cleaning in plugs. *2: For ferrule end face cleaning in adaptors



		Main Connector/Cleaner Compatibility Chart				
		Compatible Connector	Ferrule End Face Cleaner			
Single core optical connectors	MU plug	LC plug	NEOCLEAN-R2 NEOCLEAN-E1 NEOCLEAN-EZ1 NEOCLEAN-F12 NEOCLEAN-EZ1 Plus	OPTIPOP R1/R2	CLETOP-S B type CLETOP B type	
	SC plug	FC plug	ST plug	NEOCLEAN-R2 NEOCLEAN-E3 NEOCLEAN-E2 NEOCLEAN-EZ2 NEOCLEAN-EZ3 NEOCLEAN-F25	OPTIPOP R1/R2	CLETOP A/B type A type CLETOP A/B type B type
	E2000 plug	MU adaptor	LC adaptor	NEOCLEAN-E1 NEOCLEAN-EZ1 NEOCLEAN-F12 NEOCLEAN-EZ1 Plus	NEOCLEAN-S125	CLETOP stick 1.25mm type
	SC adaptor	FA plug	FAS plug	NEOCLEAN-E3 NEOCLEAN-E2 NEOCLEAN-EZ2 NEOCLEAN-EZ3 NEOCLEAN-F25	NEOCLEAN-S250	CLETOP stick 2.5mm type
Multi-core connectors	FC adaptor	FA socket	FAS socket	E2000 adaptor		
	MT plug no pin	MPO plug no pin	MTRJ plug no pin		OPTIPOP R1	CLETOP-S B type CLETOP B type NEOCLEAN-R2
	MT plug with pin	MPO plug with pin			OPTIPOP R3	CLETOP MPO type
	MPO adaptor pins yes/no	MPO plug pins yes/no			NEOCLEAN-M NEOCLEAN-M2	

Video equipment

For video equipment
Optical compound connectors



Cleaners for video equipment

Optimal cleaning for various video equipment (LEMO, Tajimi, CANARE brand, etc.)



for ODC connectors

Compatible Connectors:
MU, LC, ODC,
MF10B, MF10S,
1.25mm Ferrule Connector



The EZ1 Plus can clean 1.25mm optical connector ports and ODC plugs using the main body. In addition, you can clean plugs and ODC sockets by installing the included green attachment.



*3: For cleaning FA plugs / FAS plugs, please use NEOCLEAN-E or NEOCLEAN-EZ. *4: For cleaning E2000 plug, please use NEOCLEAN-E3 or NEOCLEAN-EZ3. *5: For cleaning ST / E2000 adaptor, please use NEOCLEAN-E3 or NEOCLEAN-EZ3. [We have cleaners for connectors not shown in the above chart, so please feel free to consult with us about any needs you may have.]